

Constellation

The Constellation X-ray Observatory



TES Development at GSFC for the XMS

Caroline Kilbourne

Goddard Space Flight Center



X-ray TES development at GSFC

S. Bandler
K. R. Boyce
R. P. Brekosky
J. A. Chervenak
E. Figueroa-Feliciano
F. M. Finkbeiner
N. Iyomoto
R. L. Kelley
C. A. Kilbourne
M. A. Lindeman
F. S. Porter
T. Saab
J. Sadleir

Principal areas of progress:


- fabrication and testing of close-packed 8x8 arrays
- absorber characterization and optimization


Additional work:

- noise characterization
- completion of 2x8 demo platform

8x8 Arrays of TES Microcalorimeters with Bi/Cu Absorbers

- First 8x8 arrays produced with high-efficiency, high-fill-factor absorbers
- We are able to continue pixel optimization studies (noise mitigation, absorber design) within these arrays
- We are also able to study methods to address heat-sinking and thermal crosstalk





8x8 array

Coil for magnetic field tests


NASA/GSFC

TRANSITION-EDGE
SENSORS

GSFC


Compact pixel overview

- **Overhanging absorbers**
 - Layers of Bi and Cu
 - Bi for high absorption efficiency
 - Cu for good thermal conductivity and for tuning the heat capacity
- TES calorimeters suspended on SiN membranes
- Reducing the heat capacity to match a lower α (since lower α associated with lower excess noise) will require using less Cu
- Internal thermal fluctuation noise that might result from removing Cu can be mitigated by making the device slower
- We will determine the overall optimization with regard to resolution, efficiency, pixel size, and count rate will be determined



Absorber composition optimization

AFM: BiCu absorber



Performed long series of measurements of $R(T)$ in Bi and Bi/Cu films


- $R(T)$ predicts thermal conductivity via Wiedemann-Franz law
- will not predict how an x-ray photon thermalizes
- important for optimizing thermal transport once energy is in the electron system
- indicative that a minimum of 0.2 microns of Cu is needed in a Cu layer on Bi to get good transport in the Cu
- consistent with AFM and SEM measurements of Bi roughness

Photo: Bi/Cu strips



Thickness: 0.10 μm


Roughness: 0.07 μm




Rough Bi surface makes Cu clumpy.

Absorber optimization

Rearranged the distribution of Bi (6.6 microns total) and Cu (0.6 microns total) to improve thermalization:





Example of scaling of time constant and resolution

*given reasonable assumptions about noise, sensitivity, and absorber optimization,
and a trade-off of time constant and resolution*

