

Constellation

The Constellation X-ray Observatory

►► Wide-Field Calorimeter Concept

Enectali Figueroa-Feliciano (GSFC)

Kent Irwin

(NIST)




What can we do to increase the field of view of the XMS?

- One of the limitations on the size of the XMS array is the number of electronic readout channels (SQUIDs)
- Energy resolution and throughput requirements place constraints on maximum number of SQUID channels
- Our strategy is to maintain the current baseline design while proposing an additional array that will be optimized for field of view.
- To increase the number of pixels, we look at technology extensions which may enable more SQUID channels for the same requirements.
- A further increase is obtained by relaxing the throughput and energy resolution requirements.
- Further increase in FOV could be obtained by using Position-Sensitive Devices.

XMS-centric view of Optical Bench vs. Formation Flying



Issues	Optical Bench	Formation Flying
Count Rate	Limited by time constants -> affects FOV. 4 telescopes better than 1 telescope	Defocusing would greatly increase achievable count rate, and would offset the increase in count rate associated with 1 telescope.
Plate Scale	10-25 m Focal Length Ideal for 5" pixels	For 50 m Focal length, 5" pixels are harder, and may impact Energy Resolution. Physical size of array may limit FOV. 2.5" pixels are better.
Multiple Instruments	Would require mechanical translation stage	Easy with Formation Flying
Servicability	1 detector suite for the entire mission.	Can possibly upgrade detectors, add capability, etc.

High-Resolution events as a function of count rate




HPD = 10'' 5'' pixel
HPD = 5'' 2.5'' pixel
100 μsec decay time

***A 1 mCrab source puts
80 counts per second
Distributed through the
XMS array***





High-Resolution events as a function of count rate




HPD = 10'' 5'' pixel
HPD = 5'' 2.5'' pixel
500 μ sec decay time

***A 1 mCrab source puts
80 counts per second
Distributed through the
XMS array***





High-Resolution events as a function of count rate




HPD = 10'' 5'' pixel
HPD = 5'' 2.5'' pixel
1000 μ sec decay time

***A 1 mCrab source puts
80 counts per second
Distributed through the
XMS array***



XMS-W: A High-Energy-Resolution Wide-Field Camera Concept



Baseline

32x32 1 kilopixel

2.5 arcmin Narrow-Field

High-Throughput

High-Resolution Imager

100 μ sec decay time

2-4 eV FWHM

128x128 16 kilopixel

10 arcmin Wide-Field Camera

500-1000 μ sec decay time

4 eV FWHM

256x256 65 kilo-pixel

20 arcmin Wide-Field Camera

Using Position-Sensitive Detectors

500-1000 μ sec decay time

**Four times lower maximum
count rate than 10 arcmin camera**

5-8 eV FWHM

Soft X-ray Imager

TBD - 1 keV

0.5 eV FWHM @ 500 eV



100 μ sec decay time

Assumes 5" pixels

Multiplexing very large TES arrays

- Assuming 100 MHz open-loop bandwidth and fast room-temperature time-division electronics.
- Optimistic scaling from present circuits.
- Preliminary models – more detailed full system Monte Carlo models in process

The number of pixels MUXed per column vs. τ and energy resolution



A 128 \times 128 array would potentially require a total of 8 HEMT amplifiers, 128 address lines, and 128 1st-stage SQUID feedback lines